

Installation: Z-100 Clip with HB6 Bar

Installation

APPLICATION

For mounting fiberglass acoustical wall panels with two-part clips

INSTRUCTIONS

1. Lay out panel location on the wall
2. Fasten HB6 bars to the wall 48" O.C.
3. Impale Z-100 clips to the back of the panels matching layout of the HB6 bars.
4. If panel dimension is less than 48", space clips evenly.
5. Lift panel so Z-100 clips in back of panel are above HB6 bars. Drop panel down until Z-100 clips fully engage in HB6 bars.
6. This installation technique will leave a 3/4" reveal between the ceiling and the top of the panel.
7. Use the following guide to determine the number of clip locations required:

<u>Panel Size</u>	<u># of I-CLIPS</u>
16 sqft or less	4
17 to 32 sqft	6
33 to 50 sqft	8

