

Installation: SI-CLIPS & Adhesive

Installation

APPLICATION

This installation technique combines the performance of adhesive with our SI-CLIPS to hold them in place while the adhesive dries. This allows you to install panels without any bottom support. You are also able to install panels tight to the ceiling.

INSTRUCTIONS

1. Lay out panel location on the wall
2. Fasten SI-CLIPS to the wall at the following rate: Less than 16 sqft = 2 SI-CLIPS, 16 sqft or more = 4 SI-CLIPS. They only need to hold the panel in place for 48 hours while the adhesive dries.
3. Use only water-based, heavy-bodied adhesive. We recommend using WW Henry 440 Cove Base Adhesive. **DO NOT APPLY ADHESIVE IN A RIBBON PATTERN.**
4. Walls must be primed or painted with no grease, dust or dirt. Walls should be even, with no protruding nails or screws.
5. With a putty knife, size the back of the panel by applying a thin coat of adhesive, approximately 4"x4" square, 18" O.C. across the back of the panel.
6. Place adhesive dabs, about the size of a large egg, centered on each 4"x4" sized area.
7. Position the wall panel at the installation location. Press the panel straight to the wall, ensuring that the SI-CLIPS are embedded in the back.

